

## ADELAIDE PTS -- PORT LINE -- SIGNAL LOCATIONS

Torrens Rvr Jcn - Outer Harbor					DOWN MOVEMENT	Torrens Rvr Jcn - Outer Harbor					UP MOVEMENT	RETURN TO ADELAIDE MENU
Signal Number	Signal Type	Km	GPS	Track	Signal Number	Signal Type	Km	GPS	Track			
DO NOT USE THIS DATA FOR OPERATIONAL PURPOSES WITHOUT CHECKING						DO NOT USE THIS DATA FOR OPERATIONAL PURPOSES WITHOUT CHECKING						
SIGNAL TYPES DEFINED GENERICALLY ONLY						SIGNAL TYPES DEFINED GENERICALLY ONLY						

REFER TO SEPARATE LIST FOR ADELAIDE STATION @ SLA000

TORRENS JUNCTION					DOWN
271	Absolute	1.546	-34.914235,138.583514	Down Port Main	
<i>In Section (Bowden - Kilkenny)</i>					
351	Permissive	2.660		Down Main	
353	Permissive	3.401	-34.901936,138.570157	Down Main	
451	Permissive	4.464	-34.895439,138.561664	Down Main	
551	Permissive	5.281	-34.890813,138.555646	Down Main	
651	Permissive	6.036	-34.885802,138.549114	Down Main	
<i>WOODVILLE</i>					
653	Permissive	6.492	-34.883007,138.545453	Single line	
751	Absolute Jcn YL	6.882	-34.879941,138.541453	Single line	
753	Absolute	7.506	-34.876660,138.537032	Platform 1	
851	Absolute	7.531	-34.876600,138.537120	Platform 2	
853	Absolute Junction	7.919	-34.876039,138.533294	Down Grange Branch	
861	Absolute	8.245	-34.876659,138.529750	Grange Branch	
<i>In Section (St Clair - Alberton)</i>					
951	Permissive	8.552	-34.870283,138.529028	Single line	

GRANGE BRANCH				
<i>ALBERT PARK</i>				
861	Absolute	8.245	-34.876658,138.529754	Single Line
<i>GRANGE</i>				

TORRENS JUNCTION					UP
272	Absolute Junction	1.556	-34.914132,138.583572	Up Main	
352	Absolute	2.644	-34.906527,138.576331	Up Main	
<i>In Section (Bowden - Kilkenny)</i>					
354	Permissive	3.452	-34.901703,138.570027	Up Main	
452	Permissive	4.123	-34.897423,138.564447	Up Main	
552	Permissive	4.915	-34.892620,138.558197	Up Main	
652	Permissive	5.500	-34.889000,138.553456	Up Main	
654	Permissive	5.825	-34.887023,138.550858	Up Main	
656	Permissive	6.151	-34.885021,138.548292	Up Main	
658	Permissive	6.500	-34.882921,138.545526	Up Main	
752	Permissive	6.831	-34.880799,138.542817	Up Main	
<i>WOODVILLE</i>					
758	Fixed Red	7.403	-34.877399,138.538241	Down Port Main	
756	Absolute Junction	7.393	-34.877433,138.538147	Platform 1	
754	Absolute	7.403	-34.877365,138.538271	Single line	
852	Absolute Junction	7.812	-34.875810,138.534274	Up Grange Branch	
862	Absolute Junction	8.040	-34.876083,138.531744	Grange Branch	
854	Absolute YL	7.998	-34.873658,138.533482	Up Port Main	
952	Permissive	8.977	-34.867325,138.526050	Up Port Main	
<i>In Section (St Clair - Alberton)</i>					
1052	Permissive	10.154	-34.858561,138.518832	Up Main	

ALBERT PARK				
864	Absolute	8.355	-34.876980,138.528711	Single Line
962	Permissive	8.996	-34.881079,138.523637	Single Line
<i>GRANGE</i>				
1362	Absolute	12.885	-34.899899,138.491471	Single Line

continued on Page 2

